iBook G4 12" 1.33 GHz Battery Replacement

Written By: Walter Galan



INTRODUCTION

Changing the battery is easy -- all you need is a coin.

TOOLS:

- Coin (1)

PARTS:

- iBook G3 or G4 12" Replacement Battery (New) (1)

Step 1 — Battery





- Lay your iBook upside down on a flat surface.
- Use a coin to rotate the battery locking screw 90 degrees clockwise.
- Lift the battery out of the computer.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-15 08:57:06 PM.